

FDT compatibility statement:

- MACTek is committed to creating products with the broadest support possible.
- All VIATOR HART Interfaces are designed to appear and function as standard Windows COM ports. This allows all VIATOR interfaces to work with all Windows based HART communication software applications having the capability to communicate via a COM port. Examples include, PDM, AMS, ValveLink, TOF Tool, FieldMate, FieldCare and FDT frame applications such as PACTware.
- Use of VIATOR Interfaces with FDT frame applications
 - To communicate with HART devices having a HART device DTM:
 - Install the serial HART commDTM (from Codewrights) on your PC host
 - Install the deviceDTM and associate it to the HART commDTM
 - Attach your VIATOR interface to your serial port or USB port and associate the HART commDTM to the COM port number to which the interface is attached
 - To communicate with HART devices that do not have a HART device DTM
 - Install the serial HART commDTM (from Codewrights) on your PC host
 - Install the Generic HART DTM (from ICS) and associate it to the commDTM
 - Attach your VIATOR interface to your serial port or USB port and associate the HART commDTM to the COM port number to which the interface is attached
- Please contact MACTek if you need assistance configuring your VIATOR interface in any Windows based application.